MOUNTING INSTRUCTIONS

6857 安裝 說 明

- 1.) Use **Bracket** as template to locate appropriate drilling centers with pencil. 使用固定鐵片和鉛筆在預定鑽孔的位置,畫上記號.
- 2.) Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert Plastic Anchors. 當安裝在水泥牆,使用1/4英时鑽頭,鑽孔深度4公分,崁入塑膠塞並使之齊平於
- 3.) Attach **Bracket** to wall with **Wall Screws**. 將固定鐵片以螺絲鎖在牆面上.

牆面.

JUSTIME

4.) Locate the Main Part on the Bracket and secure with Set Screw. 在固定鐵片上面掛住產品本體,並以螺絲起子由下方鎖緊埋頭螺絲,完成安裝 程序.



巧時代 ST SHENG TAI BRASSWARE CO., LTD.

